


MONITOR SPEAKER

MSP5A

Owner's manual Bedienungsanleitung Mode d'emploi Manual de instrucciones 使用说明书





CAUTION: TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE COVER (OR BACK). NO USER-SERVICEABLE PARTS INSIDE. REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.

The above warning is located on the rear of the unit

Explanation of Graphical Symbols



The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the product.



The lightning flash with arrowhead symbol within an equilateral triangle is intended to alert the user to the presence of uninsulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.

IMPORTANT SAFETY INSTRUCTIONS

- Read Instructions All the safety and operating instructions should be read before the appliance is operated.
- Retain Instructions The safety and operating instructions should be retained for future reference.
- Heed Warnings All warnings on the appliance and in the operating instructions should be adhered to.
- Follow Instructions All operating and use instructions should be followed.
- Water and Moisture The appliance should not be used near water – for example, near a bathtub, washbowl, kitchen sink, laundry tub, in a wet basement, or near a swimming pool, and the like.
- Carts and Stands The appliance should be used only with a cart or stand that is recommended by the manufacturer.
 - 6A An appliance and cart combination should be moved with care.

 Quick stops, excessive force, and uneven surfaces may cause the appliance and cart combination to overturn.
- Wall or Ceiling Mounting The appliance should be mounted to a wall or ceiling only as recommended by the manufacturer.
- 8. Ventilation The appliance should be situated so that its location or position does not interfere with its proper ventilation. For example, the appliance should not be situated on a bed, sofa, rug, or similar surface that may block the ventilation openings; or, placed in a built-in installation, such as a bookcase or cabinet that may impede the flow of air through the ventilation openings.
- Heat The appliance should be situated away from heat sources such as radiators, heat registers, stoves, or other appliances (including amplifiers) that produce heat.

- Power Sources The appliance should be connected to a
 power supply only of the type described in the operating
 instructions or as marked on the appliance.
- Grounding or Polarization The precautions that should be taken so that the grounding or polarization means of an appliance is not defeated.
- 12. Power-Cord Protection Power-supply cords should be routed so that they are not likely to be walked on or pinched by items placed upon or against them, paying particular attention to cords at plugs, convenience receptacles, and the point where they exit from the appliance.
- Cleaning The appliance should be cleaned only as recommended by the manufacturer.
- Nonuse Periods The power cord of the appliance should be unplugged from the outlet when left unused for a long period of time.
- 15. Object and Liquid Entry Care should be taken so that objects do not fall and liquids are not spilled into the enclosure through openings.
- 16. Damage Requiring Service The appliance should be serviced by qualified service personnel when:
 - A. The power-supply cord or the plug has been damaged; or
 - B. Objects have fallen, or liquid has been spilled into the appliance; or
 - C. The appliance has been exposed to rain; or
 - D. The appliance does not appear to operate normally or exhibits a marked change in performance; or
 - E. The appliance has been dropped, or the enclosure damaged.
- 17. Servicing The user should not attempt service the appliance beyond that described in the operating instructions.

MSP5A

使用说明书

感谢您购买雅马哈 MSP5A 监听音箱。MSP5A 特有的紧凑型低音反射音箱,带有一个 12cm 双向圆锥形扬声器,和一个 2.5cm 钛合金半圆形扬声器。

该双功率放大器扬声器系统逼真再现声音原貌,具有广泛用途,可用于个人家庭录音,也可用于要求严格的专业场合。请认真阅读本使用说明书,确保能长久使用 MSP5A,发挥其最佳效果。并请您妥善保管本手册。

注意事项

*请在操作使用前,首先仔细阅读下述内容** 请将本手册存放在安全的地方,以便将来随时参阅。



为了避免因触电、短路、损伤、火灾或其它危险可能导致的严重受伤甚至死亡,请务必遵守下列基本注意事项。这些注意事项包括但不限于下列情况:

电源/电源线

- 只能使用本设备所规定的额定电压。所要求的电压被印在本设备的铭牌上。
- 请勿将电源线放在热源如加热器或散热器附近,不要过分弯折 或损伤电源线,不要在其上加压重物,不要将其放在可能被踩 踏引起绊倒或可能被碾压的地方。

请勿打开

请勿打开本设备并试图拆卸其内部零件或进行任何方式的改造。本设备不含任何用户可自行修理的零件。若出现异常,请立即停止使用,并请有资格的 YAMAHA 维修人员进行检修。

关于潮湿的警告

- 请勿让本设备淋雨或在水附近及潮湿环境中使用,或将盛有液体的容器放在其上,否则可能会导致液体溅入任何开口。
- 切勿用湿手插拔电源线插头。

当意识到任何异常情况时

- 若电源线出现磨损或损坏,使用设备过程中声音突然中断或因此而发出异常气味或冒烟,请立即关闭电源开关,从电源插座中拔出电源线插头,并请有资格的YAMAHA维修人员对设备进行检修。
- 若本设备发生摔落或损坏,请立即关闭电源开关,从电源插座 中拔出电源线插头,并请有资格的YAMAHA维修人员对设备进行 检修。



为了避免您或周围他人可能发生的人身伤害、设备或财产损失,请务必遵守下列基本注意事项。这些注意事项 包括但不限于下列情况:

电源/电源线

- 当准备长期不使用本设备或发生雷电时,请从电源插座中拔出 电源线插头。
- 当从本设备或电源插座中拔出电源线插头时,请务必抓住插头而不是电源线。直接拽拉电源线可能会导致损坏。

安放位置

- 若设备安装需要进行建筑工程,请务必向有资格的 YAMAHA 维修服务人员咨询,然后选择适当的装备硬件以及可承受本设备重量的安装场所,避免安放在经常震动的场所,并确认使用指定的硬件。建筑和安装工程完成后,请有资格的 YAMAHA 维修服务人员对设备进行定期检查。
- 如果您使用支架,请确认支架的规格,以及支架是否能安全支 撑扬声器的重量。在支架安放位置的周围不要安排人数过多, 以免设备被碰落,造成内部零件受损。
- 移动设备之前,请务必拔出所有的连接电缆。

- 为了避免操作面板发生变性或损坏内部组件,请勿将本设备放在有大量灰尘、震动、极端寒冷或炎热(例如阳光直射,或靠近加热器的地方)的环境中。
- 请勿将本设备放在不稳定的地方,否则可能会导致突然翻倒。
- 请勿阻塞通风孔。本装置在背面 都有通风孔,可防止温度升得 过高。特别是,严禁将设备安放在任何通风不良的地方,例如 书架上或储物柜内。
- 请勿将本设备靠在墙壁或其它设备上,否则可能会导致空气循环不良,进而引起设备过热。请在本设备与周围墙壁或其它设备之间预留足够的空间:两侧至少5cm,后面至少10cm,上面至少10cm。

连接

 将本设备连接到其它设备之前,请关闭所有设备的电源开关。 在打开或关闭所有设备的电源开关之前,请将所有音量都调到 最小。

操作处理注意事项

- 避免外部异物(如纸,塑料,金属等)插入或落入低音反射端口(在箱体前部的两个孔洞)。如果发生上述情况,请立即关闭电源,拔掉插头。后後请雅马哈专业服务人员检查设备。
- 请勿长时间持续在很高或不舒服的音量水平使用本设备,否则可能会造成永久性听力损害。若发生任何听力损害或耳鸣,请夫看医生。
- 若声音失真,请勿操作本设备。在这种状态下长时间使用可能会导致过热或火灾。
- 请勿将身体压在本设备上或在其上放置重物,操作按钮、开关或插口时要避免过分用力。

XLR 型插口应按下图所示进行布线 (IEC60268 标准): 针 1: 地线, 针 2: 热线 (+) 和针 3: 冷线 (-)。

对由于不正当使用或擅自改造本设备所造成的损失、数据丢失或破坏,YAMAHA 不负任何责任。

当不使用本设备时, 请务必关闭其电源。

- 虽然扬声器带有磁性屏蔽,但是如出现非正常的色彩变化或影像变形,仍需要将视频监视器或显示器搬开,使其远离扬声器。
- 如果将扬声器放置在比较滑的平面上,请将包装中带有的橡胶脚垫安装在扬声器底部,这样可以防滑。
- 低音反射端口中有气流出入属于正常情况,而且扬声器在播放 带有重低音效果的音像材料时经常会有此类情况发生。


手机的干涉

在音箱附近使用手机时会产生噪音,如果有噪音发生 应将手机远离音箱。

^{*}在本手册中的说明只是针对一般目的的解释。有可能不完全对应实际操作时的具体情况。

^{*}客户使用手册中梭使用的公司名称和产品名均为各所有者的商标或者登录商标。

前面板 / 后面板




① 电源指示器

打开位于后面板上的 POWER (电源) 开关时 (③),指示器的灯点亮为绿色。

② VOL (Volume) control

控制旋扭可以让您调节总音量。逆时针方向旋转 控制钮降低音量。顺时针方向旋转控制钮提高音 量。



③ POWER (电源) 开关

此开关用于控制 MSP5A 音箱的电源。当您打开开 关,前面板上的绿色电源指示器(①)点亮。

④ TRIM (调节) 开关

这些开关可用于调节 MSP5A 音箱的低音和高音。

LOW (低): 四种位置

LOW 开关用于调整低音范围。设定 "+1" 时,低 音范围增加 1.5dB。设定 "-1" 时, 低音范围降 低 1.5dB。

(参考表现示意图)

HIGH (高): 三种位置

HIGH 开关用于调整高音。 设定 "+1"时, 高音范 围增加 1.5dB。设定 "-1"时,高音范围降低 1.5dB_o

(参考表现示意图)

⑤ INPUT (输入) 插口

LINE 1

XLR 型接口用于对称连接。

LINE 2

非立体声电话接口用于非对称线性输出连接。

规格

通用規格

类型 放大双向低音反射有源扬声器

(BI-AMP)

交叉频率 2.5 kHz

重量 7.5 公斤

揚聲器

扬声器机体

低频: 12 厘米圆锥体 (4Ω) ,磁性屏蔽) 高频: 2.5 厘米钛合金半圆形 (6Ω) ,磁性屏蔽) 附件 类型: 低音反射

体积: 6.3 ℓ

放大器

最大输出功率

低频: 400Hz 时为 40W, THD=0.02%, RL=4 Ω 高频: 10kHz 时为 27W, THD=0.02%, RL=6 Ω

输入敏感度/阻抗

Line 1: +4dB/10k Ω (XLR 对称型) Line 2: -10dB/10k Ω (电话非对称型) 信噪比.....≧ 100dB (A 重量) 控制

TRIM (调节) 开关

LOW (低): 4 种位置

(60Hz 时, +1.5dB, 0dB, -1.5dB, -3dB)

HIGH (高): 3 种位置

(15kHz 时, +1.5dB, 0dB, -1.5dB) POWER (电源) 开关: ON (开) /OFF (关)

VOL control

电源指示器 绿灯亮


欧洲: AC230V, 50Hz 中国: AC220V, 50Hz 韩国: AC220V, 60Hz 其他: AC240V, 50Hz


功率损耗...... 60W

附件......防滑垫 2块,使用说明书

此使用说明书中的规格与描述仅供信息参考。雅 马哈公司保留随时更改和调整产品与其规格的权 利,无须事先通知。由于说明、设备和可选件可 能和每个现场产品不同,所以请和您的 YAMAHA 经 销商确认。


尺寸






单位: 毫米

Block Diagram/Blockschaltbild/Schéma/ Diagrama en bloques/部件图



Performance graph/Frequenzgrafik/Graphique de performance/Gráfico de operación/表现示意图

1 W at 1 kHz / 1 m on Axis An anechoic room



For details of products, please contact your nearest Yamaha representative or the authorized distributor listed below.

Pour plus de détails sur les produits, veuillez-vous adresser à Yamaha ou au distributeur le plus proche de vous figurant dans la liste suivante.

Die Einzelheiten zu Produkten sind bei Ihrer unten aufgeführten Niederlassung und bei Yamaha Vertragshändlern in den jeweiligen Bestimmungsländern erhältlich.

Para detalles sobre productos, contacte su tienda Yamaha más cercana o el distribuidor autorizado que se lista debajo.

NORTH AMERICA

CANADA

Yamaha Canada Music Ltd.

135 Milner Avenue, Scarborough, Ontario, M1S 3R1, Canada Tel: 416-298-1311

Yamaha Corporation of America

6600 Orangethorpe Ave., Buena Park, Calif. 90620, USA

Tel: 714-522-9011

CENTRAL & SOUTH AMERICA

MEXICO

Yamaha de Mexico S.A. De C.V., Departamento de ventas

Javier Rojo Gomez No.1149, Col. Gpe Del Moral, Deleg. Iztapalapa, 09300 Mexico, D.F. Tel: 55-5804-0600

Yamaha Musical do Brasil LTDA.

Av. Rebouças 2636, São Paulo, Brasil Tel: 011-3085-1377

ARGENTINA

Yamaha Music Latin America, S.A.

Sucursal de Argentina Viamonte 1145 Piso2-B 1053, Buenos Aires, Argentina Tel: 1-4371-7021

PANAMA AND OTHER LATIN AMERICAN COUNTRIES

CARIBBEAN COUNTRIES Yamaha Music Latin America, S.A.

Torre Banco General, Piso 7, Urbanización Marbella, Calle 47 y Aquilino de la Guardia, Ciudad de Panamá, Panamá Tel: +507-269-5311

EUROPE

THE UNITED KINGDOM

Yamaha-Kemble Music (U.K.) Ltd.

Sherbourne Drive, Tilbrook, Milton Keynes, MK7 8BL, England Tel: 01908-366700

Yamaha Music Central Europe GmbH

Siemensstraße 22-34, 25462 Rellingen, Germany Tel: 04101-3030

SWITZERLAND/LIECHTENSTEIN

Yamaha Music Central Europe GmbH, **Branch Switzerland**

Seefeldstrasse 94, 8008 Zürich, Switzerland Tel: 01-383 3990

AUSTRIA

Yamaha Music Central Europe GmbH, **Branch Austria**

Schleiergasse 20, A-1100 Wien, Austria Tel: 01-60203900

THE NETHERLANDS

Yamaha Music Central Europe,

Branch Nederland

Clarissenhof 5-b, 4133 AB Vianen, The Netherlands Tel: 0347-358 040

BELGIUM/LUXEMBOURG

Yamaha Music Central Europe GmbH,

Branch Belgium

Rue de Geneve (Genevastraat) 10, 1140 - Brussels, Belgium

Tel: 02-726 6032

FRANCE

Yamaha Musique France

BP 70-77312 Marne-la-Vallée Cedex 2, France Tel: 01-64-61-4000

Yamaha Musica Italia S.P.A.

Combo Division

Viale Italia 88, 20020 Lainate (Milano), Italy Tel: 02-935-771

SPAIN/PORTUGAL

Yamaha-Hazen Música, S.A.

Ctra. de la Coruna km. 17, 200, 28230 Las Rozas (Madrid), Spain Tel: 91-639-8888

SWEDEN

Yamaha Scandinavia AB

J. A. Wettergrens Gata 1 Box 30053 S-400 43 Göteborg, Sweden Tel: 031 89 34 00

DENMARK

YS Copenhagen Liaison Office

Generatorvej 8B DK-2730 Herlev, Denmark Tel: 44 92 49 00

NORWAY

Norsk filial av Yamaha Scandinavia AB

Grini Næringspark 1 N-1345 Østerås, Norway Tel: 67 16 77 70

OTHER EUROPEAN COUNTRIES

Yamaha Music Central Europe GmbH

Siemensstraße 22-34, 25462 Rellingen, Germany Tel: +49-4101-3030

AFRICA

Yamaha Corporation,

Asia-Pacific Music Marketing Group

Nakazawa-cho 10-1, Hamamatsu, Japan 430-8650 Tel: +81-53-460-2313

MIDDLE EAST

TURKEY/CYPRUS

Yamaha Music Central Europe GmbH

Siemensstraße 22-34, 25462 Rellingen, Germany Tel: 04101-3030

OTHER COUNTRIES

Yamaha Music Gulf FZE

LB21-128 Jebel Ali Freezone P.O.Box 17328, Dubai, U.A.E. Tel: +971-4-881-5868

ASIA

INDONESIA

PT. Yamaha Music Indonesia (Distributor) PT. Nusantik

Gedung Yamaha Music Center, Jalan Jend. Gatot Subroto Kav. 4, Jakarta 12930, Indonesia Tel: 21-520-2577

KOREA

Yamaha Music Korea Ltd.

Tong-Yang Securities Bldg. 16F 23-8 Yoido-dong, Youngdungpo-ku, Seoul, Korea Tel: 02-3770-0660

MALAYSIA

Yamaha Music Malaysia, Sdn., Bhd.

Lot 8, Jalan Perbandaran, 47301 Kelana Jaya, Petaling Jaya, Selangor, Malaysia Tel: 3-78030900

SINGAPORE

Yamaha Music Asia Pte., Ltd.

No.11 Ubi Road 1, No.06-02 Meiban Industrial Building, Singapore Tel: 747-4374

TAIWAN

Yamaha KHS Music Co., Ltd.

3F, #6, Sec.2, Nan Jing E. Rd. Taipei. Taiwan 104, R.O.C. Tel: 02-2511-8688

THAILAND

Siam Music Yamaha Co., Ltd.

121/60-61 RS Tower 17th Floor, Ratchadaphisek RD., Dindaeng, Bangkok 10320, Thailand Tel: 02-641-2951

THE PEOPLE'S REPUBLIC OF CHINA

Yamaha Music & Electronics (China) Co., Ltd. Shanghai Branch

United Plaza 25F 1468 Nan Jing Road West Jingan Shanghai 200040, China Tel: 21-6247-2211

OTHER ASIAN COUNTRIES

Yamaha Corporation,

Asia-Pacific Music Marketing Group

Nakazawa-cho 10-1, Hamamatsu, Japan 430-8650 Tel: +81-53-460-2313

OCEANIA

AUSTRALIA

Yamaha Music Australia Ptv. Ltd.

Level 1, 99 Queensbridge Street, Southbank, Victoria 3006, Australia Tel: 3-9693-5111

COUNTRIES AND TRUST TERRITORIES IN PACIFIC OCEAN

Yamaha Corporation,

Asia-Pacific Music Marketing Group
Nakazawa-cho 10-1, Hamamatsu, Japan 430-8650 Tel: +81-53-460-2313

HEAD OFFICE

Yamaha Corporation, Pro Audio & Digital Musical Instrument Division

M.D.G., Pro Audio & Digital Musical Instrument Division, Yamaha Corporation

Nakazawa-cho 10-1, Hamamatsu, Japan 430-8650

Tel: +81-53-460-2441

Yamaha Manual Library

PA07